


9/01393  
'Male' unit

9/01394  
'Female' unit

**SPECIFICATION**



**ORDERING CODE**

9/01393 Dovetail, male unit only

9/01394 Dovetail, female unit only

9/01395 'Plant-on' Dovetail set

Finish Male, raw (bronze)  
Female, Yellow zinc-plated

**'DOVETAIL' SET  
PLANT-ON**


A 'male' wedge in forged bronze fits onto the door edge, and slides into the 'female' steel plate. This guides a door into correct alignment, prevents 'drop' on hinges, and takes vertical load off door latch.

**ORDERING CODE**

3/13520 Alignment plate, zinc-plated

3/13521 Alignment pin, zinc-plated

**SPECIFICATION**



3/13521 Pin



3/13520 Plate

**ALIGNMENT  
PLATE & PIN**

The steel pin is usually fitted to the door frame and plate to the door edge. As door closes, the 'shoulder' on the pin is drawn into the shaped slot and provides firm and positive support. Yellow zinc-plated.

9/00381  
'Female' unit



9/00380 'Male' unit  
(shown reversed  
for clarity)


**ORDERING CODE**

9/00379 Dovetail set (2), black

9/00380 Dovetail, male unit only

9/00381 Dovetail, female unit only

**SPECIFICATION**



**'DOVETAIL' SET  
PLANT-IN**

A 'female' unit is fitted into the edge of the frame, and the 'male' portion is driven in as door is closed. The 'female' unit contains a spring, supported by rubber wedges, to ensure tight, positive location and prevent rattles. Finish is black powder-coated.